USR-TCP232-M4/E45 Application Note   V1.2

1. Hardware require

USR-TCP232-410 serial device server(TCP232-E2 or TCP232-ED2 both are ok)

2. Software require

Webpage source code(the fs folder, there are html files inside)
Update tool(an exe named Html2Bin, but recently we've named it as UpgradeHtml.exe)

3. Webpage introduction

3.1. Login page


Default with USR's logo and company name.
After we type in with "admin" "admin", we will go into default config page. There are USR's logo too.

4. The Application package

The fs folder is the webpage source code inside the Serial Device Server.

Double Click exe, and select the Product u are using(TCP232-410，TCP232-E2，TCP232-ED2 belongs to M4 series),

and load webpage path.

Click the upgrade button, there will be a progress bar. 100% means you have successfully upgrade the webpage.

5. New webpage

Open the browser and you will see the new webpage you have designed.