

USR-K2 AT Command Set

(Firmware 4017)

File version: 1.0.0

Content

USR-K2 AT Command Set	1
1. What is the AT command	4
2. How to use the AT command	4
2.1. How to enter AT command mode	4
3. AT command set	4
4. AT command details	6
4.1. AT+E	6
4.2. AT+Z	6
4.3. AT+VER	6
4.4. AT+ENTM	7
4.5. AT+RELD	7
4.6. AT+MAC	7
4.7. AT+USERMAC	7
4.8. AT+WEBU	7
4.9. AT+WANN	8
4.10. AT+DNS	8
4.11. AT+WEBPORT	8
4.12. AT+UART	9
4.13. AT+SOCK	9
4.14. AT+TCPSE	10
4.15. AT+SOCKLK	10
4.16. AT+SOCKPORT	10
4.17. AT+RFCEN	11
4.18. AT+PDTIME	11
4.19. AT+REGEN	11
4.20. AT+REGTCP	12
4.21. AT+REGCLOUD	12
4.22. AT+REGUSR	12
4.23. AT+HTPTP	13
4.24. AT+HTPURL	13
4.25. AT+HTPHEAD	13
4.26. AT+HTPCHD	14
4.27. AT+HEARTEN	14
4.28. AT+HEARTTP	14
4.29. AT+HEARTTM	15
4.30. AT+HEARTDT	15
4.31. AT+SCSLINK	15
4.32. AT+CLIENTRST	15
4.33. AT+INDEXEN	16
4.34. AT+SOCKSL	16
4.35. AT+SHORTO	16

4.36. AT+UARTCLBUF.....	17
4.37. AT+RSTIM.....	17
4.38. AT+MAXSK.....	17
4.39. AT+MID.....	18
4.40. AT+H.....	18
4.41. AT+CFGTF.....	18
4.42. AT+PING.....	18
5. Contact.....	19
6. Disclaimer.....	19
7. Update History.....	19

1. What is the AT command

AT command is used for controlling module. You can use AT command to configure and query the settings.

2. How to use the AT command

For USR device is in transparent mode normally, you must enter AT command mode at first. Then you can send AT command to configure or query the settings. After you configure the USR device, you should restart the USR device to make the settings take effect. Every time module restart will work in work mode rather AT command mode.

Every AT command must add character carriage return <CR> and line feed <LF>. In Hex, <CR> is 0x0D <LF> is 0x0A.

2.1. How to enter AT command mode

Please read this FAQ about entering AT command mode.

<http://www.usriot.com/enter-serial-command-mode/>

3. AT command set

Command	Function
E	Query/Set AT command echo function enable/disable
Z	Reset the module
VER	Query module firmware version
ENTM	Exit serial AT command mode and enter work mode
RELD	Restore default settings
MAC	Query module MAC address
USERMAC	Set user editable MAC address
WEBU	Query/Set Web Server username and password
WANN	Query/Set WAN interface parameters
DNS	Query/Set DNS server address
WEBPORT	Query/Set Web Server port number
UART	Query/Set serial port parameters
SOCK	Query/Set socket parameters
TCPSE	Query/Set how to handle the old TCP connections after TCP connections arriving maximum in TCP Server mode

SOCKLK	Query TCP connection status
SOCKPORT	Query/Set local port number
RFCEN	Query/Set baud rate synchronization function enable/disable
PDTIME	Query production date
Identity packet command	
REGEN	Query/Set identity packet status
REGTCP	Query/Set identity packet sending method in TCP Client mode
REGCLOUD	Query/Set USR Cloud ID and password
REGUSR	Query/Set user editable identity packet data
HTTPD Client command	
HTPTP	Query/Set HTTP requesting method in HTTPD Client mode
HTPURL	Query/Set URL in HTTPD Client mode
HTPHEAD	Query/Set HTTP header in HTTPD Client mode
HTPCHD	Query/Set filtering HTTP header of response data enabled/disabled
Heartbeat packet command	
HEARTEN	Query/Set heartbeat packet function enabled/disabled
HEARTTP	Query/Set heartbeat packet sending method
HEARTTM	Query/Set heartbeat packet interval
HEARTDT	Query/Set user editable heartbeat packet data
Extended function command	
SCSLINK	Query/Set socket Link function enable/disable
CLIENTRST	Query/Set TCP Client mode reset function enable/disable
INDEXEN	Query/Set Index function enable/disable
SOCKSL	Query/Set non-persistent connection function enable/disable
SHORTO	Query/Set non-persistent connection function time
UARTCLBUF	Query/Set clearing serial port cache before module establishing connection function enable/disable
RSTIM	Query/Set timeout reset function time
MAXSK	Query/Set maximum client connections in TCP Serve mode
MID	Query/Set module name
H	Query help information
CFGTF	Saving current parameters as user default settings
PING	Set PING function target IP and perform a PING function

4. AT command details

Special Characters		
Character	Note	Hex
<CR>	Carriage Return	0x0D
<LF>	Line Feed	0x0A

4.1. AT+E

Parameter	Description	Default Value	Range
<Status>	Status of AT command Echo function	off	on/off
Format			
Query	AT+E<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+E=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.2. AT+Z

Format	
Set	AT+Z<CR>
Return	<CR><LF>+OK<CR><LF>

4.3. AT+VER

Parameter	Description
<VER>	Firmware version of the module
Format	
Query	AT+VER<CR>
Return	<CR><LF>+OK=<VER><CR><LF>

4.4. AT+ENTM

Format	
Set	AT+ENTM<CR>
Return	<CR><LF>+OK<CR><LF>

4.5. AT+RELD

Format	
Set	AT+RELD<CR>
Return	<CR><LF>+OK<CR><LF>

4.6. AT+MAC

Parameter	Description	Range
<MAC>	MAC address of the module.	USR MAC start with D8B04C
Format		
Query	AT+MAC<CR>	
Return	<CR><LF>+OK=<MAC><CR><LF>	

4.7. AT+USERMAC

Parameter	Description	Range
<MAC>	MAC address	USR MAC start with D8B04C
Format		
Set	AT+USERMAC=<MAC><CR>	
Return	<CR><LF>+OK<CR><LF>	

4.8. AT+WEBU

Parameter	Description	Default Value	Range
<Username>	Web Server username	admin	1~5 bytes
<Password>	Web Server password	admin	1~5 bytes

Format	
Query	AT+WEBU<CR>
Return	<CR><LF>+OK=<Username>,<Password><CR><LF>
Set	AT+WEBU=<Username>,<Password><CR>
Return	<CR><LF>+OK<CR><LF>

4.9. AT+WANN

Parameter	Description	Default Value	Range
<Mode>	Method of getting IP address	STATIC	STATIC: Get the IP address manually
			DHCP: Get the IP address automatically
<IP address>	IP address	192.168.0.7	0.0.0.0~255.255.255.255
<Mask>	Subnet mask	255.255.255.0	0.0.0.0~255.255.255.255
<Gateway>	Gateway address	192.168.0.1	0.0.0.0~255.255.255.255
Format			
Query	AT+WANN<CR>		
Return	<CR><LF>+OK=<Mode>,<IP address>,<Mask>,<Gateway><CR><LF>		
Set	AT+WANN=<Mode>,<IP address>,<Mask>,<Gateway><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.10. AT+DNS

Parameter	Description	Default Value	Range
<Address>	DNS server address	208.67.222.222	0.0.0.0~255.255.255.255
Format			
Query	AT+DNS<CR>		
Return	<CR><LF>+OK=<Address><CR><LF>		
Set	AT+DNS=<Address><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.11. AT+WEBPORT

Parameter	Description	Default Value	Range
<Port>	Web Server port number	80	1~65535

Format	
Query	AT+WEBPORT<CR>
Return	<CR><LF>+OK=<Port><CR><LF>
Set	AT+WEBPORT=<Port><CR>
Return	<CR><LF>+OK<CR><LF>

4.12. AT+UART

Parameter	Description	Default Value	Range
<Baud rate>	Baud rate	115200	600~460800bps
<Data bits>	Data bits	8	5, 6, 7, 8
<Stop bits>	Stop bits	1	1, 2
<Parity>	Parity	NONE	NONE, EVEN, ODD, MASK, SPACE
<Flow Control>	Flow Control	NFC	NFC: No flow control
Format			
Query	AT+UART<CR>		
Return	<CR><LF>+OK=<Baud rate>,<Data bits>,<Stop bits>,<Parity><Flow Control><CR><LF>		
Set	AT+UART=<Baud rate>,<Data bits>,<Stop bits>,<Parity><Flow Control><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.13. AT+SOCK

Parameter	Description	Default Value	Range
<Protocol>	Network protocol	TCPC	TCPS: TCP Server mode
			TCPC: TCP Client mode
			UDPS: UDP Server mode
			UDPC: UDP Client mode
			HTPC: HTTPD Client mode
<IP address>	Remote Server IP address (in Client mode)	192.168.0.201	0.0.0.0~255.255.255.255
<Port>	Server mode: Local port; Client mode: Remote port.	8234	1~65535

Format	
Query	AT+SOCK<CR>
Return	<CR><LF>+OK=<Protocol>,<IP address>,<Port><CR><LF>
Set	AT+SOCK=<Protocol>,<IP address>,<Port><CR>
Return	<CR><LF>+OK<CR><LF>

4.14. AT+TCPSE

Parameter	Description	Default Value	Range
<Status>	How to handle Client connection after Client connections arriving maximum in TCP Server mode	KICK	KEEP: Don't receive new TCP Client connection
			KICK: Kick-off old TCP Client connection
Format			
Query	AT+TCPSE<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+TCPSE=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.15. AT+SOCKLK

Parameter	Description	Range
<Status>	Status of TCP connection	Connect/Disconnect
Format		
Query	AT+SOCKLK<CR>	
Return	<CR><LF>+OK=<Status><CR><LF>	

4.16. AT+SOCKPORT

Parameter	Description	Default Value	Range
<Port>	Local port number	20108	0: Random port
			1-65535
Format			
Query	AT+SOCKPORT<CR>		
Return	<CR><LF>+OK=<Port><CR><LF>		

Set	AT+SOCKPORT=<Port><CR>
Return	<CR><LF>+OK<CR><LF>

4.17. AT+RFCEN

Parameter	Description	Default Value	Range
<Status>	Status of baud rate synchronization function	ON	ON/OFF
Format			
Query	AT+RFCEN<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+RFCEN=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.18. AT+PDTIME

Parameter	Description
<Data>	Production data of module.
Format	
Query	AT+PDTIME<CR>
Return	<CR><LF>+OK=<Data><CR><LF>

4.19. AT+REGEN

Parameter	Description	Default Value	Range
<Status>	Status of identity packet	OFF	MAC: 6 bytes MAC address identity packet
			Usr: User editable identity packet
			Off: Disabling the identity packet
Format			
Query	AT+REGEN<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+REGEN=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.20. AT+REGTCP

Parameter	Description	Default Value	Range
<Method>	Identity packet sending method	FIRST	FIRST: Sending identity packet before first package after establishing connection
			EVERY: Sending identity packet in every package.
			ALL: Sending identity packet with both methods.
Format			
Query	AT+REGTCP<CR>		
Return	<CR><LF>+OK=<Method><CR><LF>		
Set	AT+REGTCP=<Method><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.21. AT+REGCLOUD

Parameter	Description	Range
<ID>	USR Cloud ID	Length: 20 bytes
<Password>	USR Cloud password	Length: 8 bytes
Format		
Query	AT+REGCLOUD<CR>	
Return	<C+R><LF>+OK=<ID>,<Password><CR><LF>	
Set	AT+REGCLOUD=<ID>,<Password><CR>	
Return	<CR><LF>+OK<CR><LF>	

4.22. AT+REGUSR

Parameter	Description	Default Value	Range
<Data>	User editable identity packet data	www.usr.cn	Length: 1~40 bytes, ASCII format
Format			
Query	AT+REGUSR<CR>		
Return	<CR><LF>+OK=<Data><CR><LF>		
Set	AT+REGUSR=<Data><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.23. AT+HTPTP

Parameter	Description	Default Value	Range
<Method>	HTTP requesting method	GET	GET/POST
Format			
Query	AT+HTPTP<CR>		
Return	<CR><LF>+OK=<Method><CR><LF>		
Set	AT+HTPTP=<Method><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.24. AT+HTPURL

Parameter	Description	Default Value	Range
<URL>	HTTP URL	/1.php?	Length:1~99 bytes
Format			
Query	AT+HTPURL<CR>		
Return	<CR><LF>+OK=<URL><CR><LF>		
Set	AT+HTPURL=<URL><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.25. AT+HTPHEAD

Parameter	Description	Default Value	Range
<Header>	HTTP Header	User_Agent: Mozilla/4.0 Connection: close	Less than 199 bytes, <<CRLF>> is carriage return and line feed.
Format			
Query	AT+HTPHEAD<CR>		
Return	<CR><LF>+OK=<Header><CR><LF>		
Set	AT+HTPHEAD=<Header><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.26. AT+HTPCHD

Parameter	Description	Default Value	Range
<Status>	Status of filtering HTTP header of response data function	OFF	ON/OFF
Format			
Query	AT+HTPCHD<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+HTPCHD=<Status><CR>		
Return:	<CR><LF>+OK<CR><LF>		

4.27. AT+HEARTEN

Parameter	Description	Default Value	Range
<Status>	Status of heartbeat packet function	OFF	ON/OFF
Format			
Query	AT+HEARTEN<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+HEARTEN=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.28. AT+HEARTTP

Parameter	Description	Default Value	Range
<Type>	Heartbeat packet sending method	NET	NET: Sending heartbeat packet to network side
			COM: Sending heartbeat packet to serial side
Format			
Query	AT+HEARTTP<CR>		
Return	<CR><LF>+OK=<Type><CR><LF>		
Set	AT+HEARTTP=<Type><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.29. AT+HEARTTM

Parameter	Description	Default Value	Range
<Time>	Heartbeat packet interval	30	1~65535 seconds
Format			
Query	AT+HEARTTM<CR>		
Return	<CR><LF>+OK=<Time><CR><LF>		
Set	AT+HEARTTM=<Time><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.30. AT+HEARTDT

Parameter	Description	Default Value	Range
<Data>	Heartbeat packet data	www.usr.cn	Less than 40 bytes, in ASCII format
Format			
Query	AT+HEARTDT<CR>		
Return	<CR><LF>+OK=<Data><CR><LF>		
Set	AT+HEARTDT=<Data><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.31. AT+SCSLINK

Parameter	Description	Default Value	Range
<Status>	Status of Link function	OFF	ON/OFF
Format			
Query	AT+SCSLINK<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+SCSLINK=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.32. AT+CLIENTRST

Parameter	Description	Default Value	Range
<Status>	Status of Reset function	OFF	ON/OFF

Format	
Query	AT+CLIENTRST<CR>
Return	<CR><LF>+OK=<Status><CR><LF>
Set	AT+CLIENTRST=<Status><CR>
Return	<CR><LF>+OK<CR><LF>

4.33. AT+INDEXEN

Parameter	Description	Default Value	Range
<Status>	Status of Index function	OFF	ON/OFF
Format			
Query	AT+INDEXEN<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+INDEXEN=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.34. AT+SOCKSL

Parameter	Description	Default Value	Range
<Status>	Status of non-persistent connection function	OFF	ON/OFF
Format			
Query	AT+SOCKSL<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+SOCKSL=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.35. AT+SHORTO

Parameter	Description	Default Value	Range
<Time>	Non-persistent connection function time	3	2-255s
Format			
Query	AT+SHORTO<CR>		
Return	<CR><LF>+OK=<Time><CR><LF>		
Set	AT+SHORTO=<Time><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.36. AT+UARTCLBUF

Parameter	Description	Default Value	Range
<Status>	Status of clearing serial port cache before establishing connection function	ON	ON/OFF
Format			
Query	AT+UARTCLBUF<CR>		
Return	<CR><LF>+OK=<Status><CR><LF>		
Set	AT+UARTCLBUF=<Status><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.37. AT+RSTIM

Parameter	Description	Default Value	Range
<Time>	Timeout reset function time	3600	0, 60-65535s. 0 means closing function
Format			
Query	AT+RSTIM<CR>		
Return	<CR><LF>+OK=<Time><CR><LF>		
Set	AT+RSTIM=<Time><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.38. AT+MAXSK

Parameter	Description	Default Value	Range
<NUM>	Maximum Client connections in TCP Server mode	4	1~16
Format			
Query	AT+MAXSK<CR>		
Return	<CR><LF>+OK=<NUM><CR><LF>		
Set	AT+MAXSK=<NUM><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.39. AT+MID

Parameter	Description	Default Value	Range
<Name>	Module name	USR-K2	1~15 Bytes
Format			
Query	AT+MID<CR>		
Return	<CR><LF>+OK=<Name><CR><LF>		
Set	AT+MID=<Name><CR>		
Return	<CR><LF>+OK<CR><LF>		

4.40. AT+H

Parameter	Description
<Message>	Help message
Format	
Query	AT+H<CR>
Return	<CR><LF>+OK=<Message><CR><LF>

4.41. AT+CFGTF

Parameter	Range
<Status>	saved: Saving current settings as default settings successfully
Format	
Set	AT+CFGTF<CR>
Return	<CR><LF>+OK=<Status><CR><LF>

4.42. AT+PING

Parameter	Description	Range
<Address>	Target address of PING function	IP: 0.0.0.0~255.255.255.255
		Domain name: Less than 30 bytes
Format		
Set	AT+PING=<Address><CR>	
Return	<CR><LF>+OK<CR><LF>	

5. Contact

Company: Jinan USR IOT Technology Limited

Address: Floor 11, Building No.1, No.1166, Xinluo Street, Gaoxin District, Jinan city, Shandong province, 250101 China

Tel: 86-531-88826739

Web: www.usriot.com

Support: h.usriot.com

Email: sales@usr.cn

6. Disclaimer

This document provide the information of USR-K2 products, it hasn't been granted any intellectual property license by forbidding speak or other ways either explicitly or implicitly. Except the duty declared in sales terms and conditions, we don't take any other responsibilities. We don't warrant the products sales and use explicitly or implicitly, including particular purpose merchant-ability and marketability, the tort liability of any other patent right, copyright, intellectual property right. We may modify specification and description at any time without prior notice.

7. Update History

2017-11-02 V1.0.0 created based on firmware version 4017.